

# Hard Tri-fold Cover Installation Guide

## Tri-fold hard tonneau cover

Parts List:	Assembled Tri-fold hard Cover	1 pc
	Locking pin	4 pcs

### Step 1

Place assembled cover over cab end of truck box

### Step 2

Unfold the cover fully and adjust position over the truck bed for proper alignment on cab/tail

### Step 3

Carefully refold the cover without shifting its position on the truck bed

### Step 4

Secure the Front Clamps (left and right) by pulling the clamp handle down to clamp the metal bed wall edge of truck. Note: If necessary, adjust the clamp position by rotating the clamp on the bolt to ensure the clamp is tightly clamped on the metal bed wall edge of truck. Do not secure to only lip of bedliner or rail cap.

### Step 5

Insert locking pins into front clamps



### Step 6

With truck tailgate open and front clamps secure, completely unfold the cover. Repeat Step 4 and 5 on the two rear clamps.

## ***For Nissan/Toyota Trucks (with Utility Track channel) only***

*\*Slide the retainer plates into the side channels on the vehicle bed. ( 2 per side, 1 goes in front and 1 in back)*



*\*Attach the clamp bracket to the plate with the included allen head bolts.*



*\*Line the bracket up with the tri-fold hard cover clamp location once they are lined up. Secure bracket to the vehicle bed rail.*

*\*Secure Tri-fold Cover latches to these brackets*

### **To open the cover:**

**Release the rear clamps, fold the cover forward.**

Note 1): when folding the cover, make sure to push down & lock the rear clamps into the cross bar.



2): When cover is folded completely, secure the folded cover by fastening the straps with buckles together. Pull the straps to tighten the folded cover tightly.

#### **Attention:**

Never Drive with a cover in partially opened position. When driving, cover must be secured with 4 clamps or completely folded up and secured by front clamps and buckles.